

WING INSIGNIA DETAIL



FUSELAGE INSIGNIA DETAIL



TOP VIEW OF LEFT WING

INSIGNIA. SEE DETAIL



BOTTOM VIEW OF RIGHT WING

INSTALLATION ON WINGS.

NOTE:
INSIGNIA TO BE INSTALLED ON TOP OF LEFT WING AND ON BOTTOM OF RIGHT WING.

INSIGNIA TO BE INSTALLED AS SHOWN ON BOTH SIDES OF FUSELAGE.



INSTALLATION ON FUSELAGE

B LIMITS, SHOP PRACTICES AND FINISH, UNLESS OTHERWISE NOTED, TO BE IN ACCORDANCE WITH PIPER SPECIFICATIONS #9 AND #10

REVISIONS	DATE	BY	CHK	U.B.M.
B	[illegible]			
A	[illegible]			

MODEL	PER SHIP	NEXT ASSEMBLY	SUPERSEDES	SUPERSEDED BY
L-4A	85843			

PIPER AIRCRAFT CORP. LOCK HAVEN, PA.

PART No.	No. REQ.	MATERIAL
SCALE		

INSIGNIA

FSCM NO. 71217

84909